

Setting Date/Time/Day

This operation is possible from the Administrator station or attendant consoles and enables you to set the date, time, and day.

To set the date

1. Press a [DN] +**#651** with the handset on-hook. You hear a confirmation tone.
2. Enter the date (YYMMDD).
3. Press **Redial** You hear a confirmation tone.
4. Press **Spkr** The telephone returns to the idle mode.

To set the time

1. Press [DN] + **#652** with the handset on-hook. You hear a confirmation tone.
2. Enter the time (HHMMSS) in the 24-hour clock format. H=hour, M=minute and S=seconds.
Use leading zeros:
060530 = 6:05AM and 30 seconds;
143045 = 2:30PM and 45 seconds.
3. Press **Redial** You hear a confirmation tone.
4. Press **Spkr** The telephone returns to the idle mode.