

Toshiba DK Speed Dial Programming

SYSTEM SPEED DIALS:

- ☎ Press **PDN**
- ☎ Press **#66**
- ☎ Enter **Code** SYSTEM SPEED DIAL CODES ARE 200-899
- ☎ Dial in **telephone number**. (If long distance dial 1 area code and phone number.)
- ☎ Press **#**
- ☎ Press **Spkr**

Must be done from an administrator phone

PERSONAL SPEED DIALS:

- ☎ Do not lift the handset.
- ☎ Press **#66**
- ☎ Enter **Code** (codes are 100 through 119)
- ☎ Press **9**
- ☎ Dial in **telephone number**. (If long distance dial 1 area code and phone number.)
- ☎ Press **#**
- ☎ Press **Spkr**